



**Volvo S60**  
(2012-2013)



**Wiring Diagrams and Electric Model Year 2013**



VOLVO S60 (11-), V60

# WIRING DIAGRAM 2013



TP 39252202 Structure week 12w20

# Table of Contents 1:3

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable curtain).....	2
Explanations & Abbreviations.....	6
How to use the wiring diagrams 1:2.....	7
Electrical distribution .....	9
Overview without Start/stop function .....	9
Overview with Start/stop function .....	10
Overview, Distribution box in engine compartment .....	11
Overview, Distribution box in passenger compartment .....	12
Overview, Distribution box in cargo compartment .....	13

## Fuses

Distribution box in engine compartment F1 - F7.....	14
Distribution box in engine compartment F8 - F23.....	15
Distribution box in engine compartment F27 - F36.....	16
Distribution box in engine compartment F37 - F38.....	17
Distribution box in engine compartment F39 - F44.....	18
Central Electronic Module (CEM) F1 - F8.....	19
Central Electronic Module (CEM) F9 - F19.....	20
Central Electronic Module (CEM) F20 - F24.....	21
Distribution box in passenger compartment F1 - F17... ..	22
Distribution box in passenger compartment F18 - F30.....	23
Distribution box in engine compartment, cold zone.....	24
Distribution box in cargo compartment FA1 - FA11 .....	25
Battery PF1 - PF2.....	26

## Relays

Relays in the engine compartment .....	27
Relays in the engine compartment and passenger compartment.....	28
Relays in cargo compartment.....	29

## Ground connections

Overview.....	30
31/1 - 31/7 .....	31
31/10 - 31/15 continues .....	32
31/15 - 31/68 .....	33
31/83 - 31/89 .....	34
31/90 - 31/XX4.....	35
31/XX10 - 31/TRM .....	36

## Control modules

Overview locations.....	37
Overview designations.....	38
Central Electronic Module (CEM) 1:3 .....	39
Data communication, High speed CAN .....	42
Data communication intermediate speed CAN, LHD... ..	43
Data communication intermediate speed CAN, RHD .. ..	44
Data communication Local CAN .....	45
Data communication, LIN 1:2.....	46
Data communication MOST .....	48
Steering Wheel Module (SWM) .....	49

## Group 26 Cooling system

Cooling fan, 4-Cyl. Turbo .....	50
Cooling fan, 4-Cyl. Diesel .....	51
Cooling fan, 5-Cyl. Diesel .....	52
Cooling fan, 5-Cyl. Turbo & 6-Cyl. ....	53

## Group 27 Engine controls

Cruise control 4-Cyl. Turbo 1.6l .....	54
Cruise control 4-Cyl. Turbo 2.0l .....	55
Cruise control 4-Cyl. Diesel .....	56
Cruise control 5-Cyl. Diesel .....	57
Cruise control 5-Cyl. Turbo & 6-Cyl. ....	58
Start-/Stop function 4-Cyl. 1.6l Turbo.....	59
Start-/Stop function 4-Cyl. 1.6l Diesel DV6C .....	60
Start-/Stop function 5-Cyl. Diesel VED5 .....	61

## Group 28 Ignition and control system

Engine management system 4-Cyl. 1.6l Turbo 1:2.....	62
Engine management system 4-Cyl. 2.0l Turbo 1:2.....	64
Engine management system, 5-Cyl. Turbo 1:2.....	66
Engine management system, 6-Cyl. Turbo 1:2.....	68
Engine management system, 4-Cyl. Diesel 1:3.....	70
Engine management system, 5-Cyl. Diesel 1:3.....	73
Emission control 4-Cyl. 1.6l Turbo .....	76
Emission control 4-Cyl. 2.0l Turbo .....	77
Emission control 5-Cyl. Turbo.....	78
Emission control 6-Cyl. ....	79

## Table of Contents 2:3

### Group 32 Alternator and voltage regulator

Power supply 4-Cyl. without Start/Stop .....	80
Power supply 5-Cyl. & 6-Cyl. without Start/Stop.....	81
Power supply 4-Cyl. & 5-Cyl. with Start/Stop.....	82

### Group 33 Starting system

Starting system 4-Cyl.....	83
Starting system, 5-Cyl. & 6-Cyl.....	84

### Group 35 Lighting

High and low beam.....	85
High and low beam (Dual Xenon).....	86
Beam length adjustment, manual .....	87
Running/Parking light, Tail lights S60 .....	88
Running/Parking light, Tail lights V60 .....	89
Fog lights S60.....	90
Fog lights V60.....	91
Brake lights S60.....	92
Brake lights V60.....	93
Reversing lights S60.....	94
Reversing lights V60.....	95
Follow-me-home lighting LHD .....	96
Follow-me-home lighting RHD.....	97
Interior lighting, LHD 1:2.....	98
Interior lighting, RHD 1:2 .....	100
Active headlight .....	102
Lighting in door sill trims .....	103
Auxiliary lights.....	104

### Group 36 Additional electrical equipment

Rain sensor.....	105
Direction indicator and hazard warning flashers LHD S60 .....	106
Direction indicator and hazard warning flashers LHD V60 .....	107
Direction indicator and hazard warning flashers RHD S60.....	108
Direction indicator and hazard warning flashers RHD V60.....	109
Wiper/washer windshield.....	110
Washer headlights.....	111
Wiper/Washer rear windowV60 .....	112
Horn .....	113
Keyless vehicle 1:2.....	114
Anti-theft alarm .....	116
Parking assistance.....	117

Collision warning with power brake booster.....	118
Tire pressure monitoring system (TPMS) .....	119
Alcohol lock.....	120

### Group 37 Wiring and fuses

Diagnostics system .....	121
Outlet 12V .....	122
Outlet 12V, V60 .....	123
12 V outlet, V60 .....	124
Cable harness towbar/tow hitch 13-pin S60 .....	125
Cable harness towbar/tow hitch 13-pin V60 .....	126

### Group 38 Instruments

Seat belt reminder .....	127
Driver information module.....	128

### Group 39 Other

Audio Premium 1:3 .....	129
Audio 1:2.....	132
Cellular phone 1:2.....	134
DAB Radio .....	136
Multimedia monitor with DVD, Dual Screen (RSE) ....	137
TV receiver / TV control module S60 .....	138
TV receiver / TV control module V60 .....	139
Bluetooth Handsfree .....	140
Navigation system and Traffic information, portable..	141
Satellite radio .....	142
Parking camera rear .....	143
Parking camera rear .....	144
Parking camera wide angle front .....	145

### Group 43 Transmission

Transmission M66.....	146
Automatic transmission AWF21 .....	147
Automatic transmission MPS6.....	148
Differential Electronic Module (DEM).....	149

### Group 55 Parking brake

Electric parking brake .....	150
------------------------------	-----

### Group 59 Brake system

Brake control system & DSTC .....	151
-----------------------------------	-----

### Group 64 Steering

Speed dependent power steering.....	152
-------------------------------------	-----

# Table of Contents 3:3

## Group 76 Shock absorbers

Four-C .....	153
--------------	-----

## Group 83 Doors and openings

Central locking front doors LHD.....	154
Central locking front doors RHD.....	155
Central locking rear doors.....	156
Central locking tailgate S60.....	157
Central locking tailgate V60.....	158
Central locking fuel filler flap.....	159
Signal receiver central locking.....	160
Power windows front doors LHD .....	161
Power windows front doors RHD.....	162
Power windows rear doors .....	163
Power sunroof.....	164

## Group 84 Exterior decorative elements, etc.

Power door mirrors LHD.....	165
Power door mirrors RHD .....	166
Heated door mirrors LHD.....	167
Heated door mirrors RHD.....	168
Blind spot information system LHD.....	169
Blind spot information system RHD .....	170
Heated rear window.....	171

## Group 85 Interior equipment

Power driver's seat with memory function, LHD.....	172
Power driver's seat with memory function, RHD .....	173
Power passenger seat, LHD.....	174
Power passenger seat, RHD .....	175
Heated front seats with fans .....	176
Heated front seats without fans .....	177
Heated rear seat.....	178

## Group 87 Climate control system

Climate control system PTC-elements .....	179
Climate control system, 4-Cyl. 1:2 .....	180
Climate control system 4-Cyl. Diesel 1:2 .....	182
Climate control system 5-Cyl. & 6-Cyl. 1:2 .....	184
Parking heater, auxiliary heater .....	186
Parking heater, remote start .....	187

## Group 88 Internal equipment

Supplemental restraint system 1:2 .....	188
Rear-view mirror with automatic dimming.....	190
Remote control opener garage door.....	191
Power folding headrest.....	192

## Group 89 Body other

Radiator masking blind .....	193
------------------------------	-----

## Connectors..... 194

## Branching points .....229

## Cable harness routing in vehicle


Harness engine 4-Cyl. Turbo.....	249
Harness engine, 6-Cyl. Turbo.....	249
Harness engine, 2.0L Diesel.....	250
Harness engine, 2.4L Diesel.....	250
Engine compartment harness LHD.....	251
Engine compartment harness RHD .....	252
Harness dashboard, LHD .....	253
Harness Dashboard, RHD .....	254
Harness Floor, LHD S60.....	255
Harness Floor, RHD S60 .....	256
Floor Harness, LHD V60.....	257
Harness Floor, RHD V60 .....	258
Harness infotainment, LHD S60 .....	259
Harness infotainment, RHD S60.....	260
Harness infotainment, LHD V60 .....	261
Harness infotainment, RHD V60.....	262
Roof harness, S60 .....	263
Roof harness V60 .....	263
Center console harness.....	264
Tunnel harness .....	264
Harness front door, left .....	265
Harness front door, right .....	265
Harness rear door, left .....	266
Harness rear door, right.....	266
Trunk lid/tailgate harness, S60 .....	267
Trunk lid/tailgate harness, V60 .....	267
Harnesses rear axle.....	268

## Component illustrations .....269

## Index 1:2.....326

## List of components 1:6 .....328


# Electrical distribution Overview with Start/stop function



N00009

# Fuses

## Distribution box in engine compartment F39 - F44



### 15/31 Distribution box in engine compartment

No.	No.	Fuse function	via	A
F39	11B/39	7/15 Front heated oxygen sensor, 4-Cyl. Turbo	-	10
		7/82 Rear heated oxygen sensor bank 1, 4-Cyl. Turbo	-	
		7/15 Front heated oxygen sensor, 4-Cyl. Diesel	-	
		4/136 Radiator masking blind	-	15
			7/15 Front heated oxygen sensor, 5-Cyl. Diesel	
		7/15 Front heated oxygen sensor, bank 1, 5-Cyl. Turbo	-	
		7/215 Rear heated oxygen sensor, 5-Cyl. Turbo	-	
		8/18 EVAP valve, 5-Cyl. Turbo	-	
		7/103 Front heated oxygen sensor, bank 2, 6-Cyl.	-	
7/104 Rear oxygen sensor, bank 2, 6-Cyl.	-			
7/15 Front heated oxygen sensor bank 1, 6-Cyl. Turbo	-			
7/82 Rear heated oxygen sensor bank 1, 6-Cyl. Turbo	-			
8/18 EVAP valve, 6-Cyl. Turbo	-			
F40	11B/40	6/73 Coolant pump, 4-Cyl. Turbo, Start/Stop	2/14	10
		6/73 Coolant pump, 5-Cyl. Turbo, Start/Stop	2/14	20
		6/179 Electric oil pump, 5-Cyl. & 6-Cyl.	-	
		9/32 PTC resistor crankcase ventilation, 5-Cyl. Turbo	-	
F41	11B/41	9/38 Electrically heated fuel filter, 4-Cyl. Diesel	-	
		6/67 Pump, fuel leakage control 6-Cyl.	-	5
		9/32 PTC resistor crankcase ventilation, 5-Cyl. Diesel	-	
F42	11A/42	6/179 Electric transmission oil pump, Diesel	-	
		4/109 Glow plug control module	-	70
F43	11A/43	20/22-26 Glow plug, 5-Cyl. Diesel	4/109	
		4/71 Control module cooling fan 4-Cyl. Turbo	-	60
F44	11A/44	4/71 Cooling fan control module, 5-Cyl. Diesel & 6-Cyl.	-	80
		6/164 Electrical power steering module (EPS)	-	100

**Cable harness routing in vehicle  
Harness engine 4-Cyl. Turbo**



105127

**Cable harness routing in vehicle  
Harness engine, 6-Cyl. Turbo**



101402\_T